

LS 990; AS 500; A 550; A FLOW; A CREATION

Albrecht Jung GmbH & Co. KG

The following products are covered under this certification number 5241:

Product Name	SKU / Model #
JUNG series AS 500	
1-gang switch, 1-pole, 2-way, 10 AX 250 V ~	506U; 506EU
1-gang push switch insert, 10 AX 250 V ~, 1-pole, 2-way	506TU; 506ETU
1-gang push-button, 1-pole, 1-way NO contact 10 A 250 V ~	531U; 531EU
1-gang switch, 2 x 1-pole, 1-way, 10 AX 250 V ~	505U; 505EU
2-gang blind switch/push-button, 10 AX 250 V ~, 1-pole	509VU; 509VEU
Frame for horizontal and vertical combination	LS981WW
Frame for horizontal and vertical combination	LS982WW
Frame for horizontal and vertical combination	LS983WW
Frame for horizontal and vertical combination	LS984WW
Frame for horizontal and vertical combination	LS985WW
Surface cap 1-gang	LS581AWW
Surface cap 2-gang	LS582AWW
Surface cap 3-gang	LS583AWW
1-gang rocker for switches and push-buttons	LS990WW
1-gang rocker for switches and push-buttons with inscription field	LS990NAWW
1-gang rocker with light guide for control switches and illuminated push buttons	LS990KO5WW
2-gang rocker for series switches and double push-buttons	LS995WW
2-gang rocker for series switches and double push-buttons with lens	LS995KO5WW
2-gang rocker for blind switch with arrow symbols	LS995PWW
SCHUKO® socket	LS1520WW; LS1520NWW

SCHUKO® socket, Safety+	LS1520KIWW; LS1520NKIWW
SCHUKO® socket with inscription field	LS1520NAWW; LS1520NNAWW
SCHUKO® socket with USB charger, Safety+	LS1520-18CWW
SCHUKO® socket with USB charger, Safety+	LS1520-15CAWW
SCHUKO® socket with USB charger, Safety+	LS1520-18AWW
SCHUKO® socket, Safety+, Hinged lid	LS1520KIKLWW; LS1520NKIKLWW
Room controller display compact module, 3-gang	4093KRMTSD
Cover kit 3-gang for room controller	LS4093TSAWW
Standard push-button module, 2-gang	4072TSM
Standard push-button module, 3-gang	4073TSM
Standard push-button module, 4-gang	4074TSM
Cover kit 2-gang	LS402TSAWW
Cover kit 3-gang	LS403TSAWW
Cover kit 4-gang	LS404TSAWW
Room controller display compact module, 2-gang	LS5192KRMTSD
Room controller display compact module, 4-gang	LS5194KRMTSD
Standard push-button module, 1-gang	LS5071TSM
Standard push-button module, 2-gang	LS5072TSM
Standard push-button module, 3-gang	LS5073TSM
Standard push-button module, 4-gang	LS5074TSM
Cover kit 1-gang	LS501TSAWW
Cover kit 2-gang	LS502TSAWW
Cover kit 3-gang	LS503TSAWW
Cover kit 4-gang	LS504TSAWW
Automatic switch Universal, 1.10 m	LS3181-1WW
Centre plate 2-gang modular jack IAE/UAESockets, 2 x 8-pole	LS969-2NAUAWW
Centre plate 1-gang modular jack IAE/UAESockets, 2 x 8-pole with inscription field	LS969-1NAUAWW

JUNG series A 550	
Frame for horizontal and vertical mounting (break-proof)	AS581BFWW
Frame for horizontal and vertical mounting	AS581WW
Frame for horizontal and vertical mounting (break-proof)	AS582BFWW
Frame for horizontal and vertical mounting	AS582WW
Frame for horizontal and vertical mounting (break-proof)	AS583BFWW
Frame for horizontal and vertical mounting	AS583WW
Frame for horizontal and vertical mounting (break-proof)	AS584BFWW
Frame for horizontal and vertical mounting	AS584WW
Frame for horizontal and vertical mounting (break-proof)	AS585BFWW
Frame for horizontal and vertical mounting	AS585WW
Rocker for switches and push-buttons (break-proof)	AS591BFWW
Rocker for switches and push-buttons	AS591WW
Rocker with light guide for control switches and illuminated push buttons (break-proof)	AS591KO5BFWW
Rocker with light guide for control switches and illuminated push buttons	AS591KO5WW
Rocker for series switches and double push-buttons (break-proof)	AS591-5BFWW
Rocker for series switches and double push-buttons	AS591-5WW
Rocker for series switches and double push-buttons, with fibre (break-proof)	AS591-5KO5BFWW
Rocker for series switches and double push-buttons, with light	AS591-5KO5WW
Rocker for blinds switch/button (break-proof)	AS591-5PBFWW
Rocker for blinds switch/button	AS591-5PWW
SCHUKO® socket outlet (break-proof)	A1520BFWW; A1520NBFWW
SCHUKO® socket outlet	A1520WW; A1520NWW
SCHUKO® socket outlet with contact protection (break-proof)	A1520BFKIWW; A1520NBFKIWW
SCHUKO® socket outlet with contact protection	A1520KIWW; A1520NKIWW
SCHUKO® socket outlet with labelling field (break-proof)	A1520BFNAWW; A1520NBFAWW
SCHUKO® socket outlet with labelling field	A1520NAWW; A1520NNAWW

SCHUKO® socket outlet with USB charger	A1520-18AWW
SCHUKO® socket outlet with USB charger	A1520-18CWW
SCHUKO® socket outlet with USB charger	A1520-15CAWW
SCHUKO® socket outlet with hinged cover and contact protection (break-proof)	A1520BFKIKLWW; A1520NBFKIKLWW
SCHUKO® socket outlet with hinged cover and contact protection	AS1520KLWW; AS1520NKLWW
Key set 2 gang	A402TSAWW
Key set 3-fold	A403TSAWW
Key set 4 gang	A404TSA
Push-button set, 1-gang, complete	A501TSAWW
Push-button set, 2-gang, complete	A502TSAWW
Key set 3-fold, complete	A503TSAWW
Key set 4gang, complete	A504TSAWW
Automatic switch 1.10 m	A3181WW
Cover IAE/UAE junction box (break-proof)	A569-1BFPLUAWW
Cover IAE/UAE junction box	A569-1PLUAWW
Cover for IAE/UAE junction box UAE 2 x 8 UPO (break-proof)	A569-2BFPLUAWW
JUNG series A CREATION	
Frame for horizontal and vertical mounting (break-proof)	A5581BFWW
Frame for horizontal and vertical mounting (break-proof)	A5582BFWW
Frame for horizontal and vertical mounting (break-proof)	A5583BFWW
Frame for horizontal and vertical mounting (break-proof)	A5584BFWW
Frame for horizontal and vertical mounting (break-proof)	A5585BFWW
Rocker for switches and push-buttons (break-proof)	A590BFWW
Rocker for switches and push-buttons	A590WW
Rocker for switches and push buttons with label field (break-proof)	A590BFNAWW
Rocker with light guide for control switches and illuminated push buttons (break-proof)	A590BFKO5WW
Rocker with light guide for control switches and illuminated push buttons	A590KO5WW

Rocker for series switches and double push-buttons (break-proof)	A595BFWW
Rocker for series switches and double push-buttons	A595WW
Rocker for series switches and double push-buttons, with fibre (break-proof)	A595BFKO5WW
Rocker for series switches and double push-buttons, with light	A595KO5WW
Rocker for blinds switch/button (break-proof)	A595BFPWW
Rocker for blinds switch/button	A595PWW
Frame for horizontal and vertical mounting (break-proof)	AC581BFWW
Frame for horizontal and vertical mounting	AC581WW
Frame for horizontal and vertical mounting (break-proof)	AC582BFWW
Frame for horizontal and vertical mounting	AC582WW
Frame for horizontal and vertical mounting (break-proof)	AC583BFWW
Frame for horizontal and vertical mounting	AC583WW
Frame for horizontal and vertical mounting (break-proof)	AC584BFWW
Frame for horizontal and vertical mounting	AC584WW
Frame for horizontal and vertical mounting (break-proof)	AC585BFWW
Frame for horizontal and vertical mounting	AC585WW
JUNG series A FLOW	
Frame for horizontal and vertical combination (break-proof)	AF581BFWW
Frame for horizontal and vertical combination (break-proof)	AF582BFWW
Frame for horizontal and vertical combination (break-proof)	AF583BFWW
Frame for horizontal and vertical combination (break-proof)	AF584BFWW
Frame for horizontal and vertical combination (break-proof)	AF585BFWW